



Government of **Western Australia**
Department of **Mines, Industry Regulation and Safety**
Building and Energy

Guidelines for the safety of buildings near network operator electrical assets

Latest: Draft 26 Feb 2020.

Published Month 2020

Preface

These guidelines for safety of buildings near network operator assets are issued under Section 33AA of the *Electricity Act 1945*.

The risks and potential consequences of an electrical incident involving building encroachments too near network operator assets are significant, especially for high voltage. The danger justifies stringent safety design criteria for buildings to prevent injury to persons and major damage to electrical installations and buildings.

I strongly recommend compliance with the information set out in these Guidelines.



Saj ABDOOLAKHAN

DIRECTOR OF ENERGY SAFETY

Contents

Preface	2
Summary	4
1 Introduction	5
1.1 Duty of care	5
1.2 Electrical risks	5
1.3 Definitions	6
2 Overhead power lines	6
2.1 General	6
2.2 Technical requirements	6
2.3 Structure clearances	6
2.4 Consideration for construction and maintenance	8
3 Underground power cables	8
3.1 General	8
3.2 Equipment types	8
3.3 Technical requirements	8
3.4 Dial Before You Dig	8
4 Network operators	8
4.1 Network operator contacts	9

Summary

- These Guidelines have been produced to assist property owners, surveyors, planners, architects, builders and local governments to give due consideration to safe clearances from network operator overhead and underground electricity infrastructure when designing and planning buildings, signs and other structures.
- These guidelines complement, and should be read with, other related documents including (but not limited to):
 - The Electricity (Network Safety) Regulations 2015.
 - Western Australian Electrical Requirements (WAER).
 - Relevant technical standards.
 - *Occupational Safety and Health Act 1984*.
 - Occupational Safety and Health Regulations 1996.
- Technical requirements for design and construction purposes are covered by legislation and technical standards and are not repeated in these Guidelines.

DRAFT

1 Introduction

1.1 Duty of care

The designers, constructors and owners of buildings share responsibility for the safety of people and property in relation to buildings sited near network operator electrical assets.

1.2 Electrical risks

The most common risks of death or injury caused directly or indirectly by electricity are:

- electric shock;
- arcing, explosion or fire; and
- toxic materials released by burning and arcing associated with electrical equipment.

Electric shocks from electrical equipment may also lead to related injuries, including falls from ladders, scaffolds or other elevated work platforms. Other shock related injuries or illnesses may include muscle spasms, palpitations, nausea, vomiting, collapse and unconsciousness.

Under Occupational Health & Safety legislation, the responsible person has the primary duty to ensure, so far as is reasonably practicable, that workers and other persons at the workplace are not exposed to electrical risks. This duty requires eliminating or minimising and managing these risks.

1.3 Definitions

For the purposes of these guidelines:

Responsible person is the person responsible for the safety of people and property in relation to the surveying, planning, designing, building management and conduct of undertakings at those properties. The *Occupational Safety and Health Act 1984* and the Occupational Safety and Health Regulations 1996 establish duties upon a number of persons in respect to workplaces.

Network operator means a person who is a network operator under the Electricity (Network Safety) Regulations 2015.

2 Overhead power lines

2.1 General

Overhead power lines are predominately located in the road reserve. However, there are locations where power lines have been lawfully placed on private land, and they remain the property of the network operator. The network operator owner is deemed to have right of access to these assets.

Certain power lines may exist within a land easement taken out over a property by a network operator. Where an easement exists, it is incumbent on the responsible person to consult with and gain approval from the network operator for any activity within the easement.


2.2 Technical requirements

Clearances to overhead power lines are governed by their operating voltage. The table below provides the minimum separation for the voltages commonly used. The clearance measurement is from the overhead cable, wire or conductor.

Clearance must be maintained at all times. Therefore, sag and sway of power line conductors, particularly mid-way between power poles, needs to be considered in addition to the distances listed. Sag and sway are influenced by varying weather conditions of wind and temperature, electrical power loading on power lines and the span length between power poles. Sag and sway may require a case by case consideration as determined by the network operator.

2.3 Structure clearances

The minimum clearance from the overhead power line wires to any building or structure is shown in the following diagram. It is common for power lines to have multiple voltage circuits on a single pole.



Clearances from structures^{1♦}

[♦] Reproduced with the permission of Standards Australia Limited © 2016. Copyright in AS/NZS 7000:2016 vests in Standards Australia Limited and Standards New Zealand

Clearances for the different voltages (U volts)♦

Clearance	U ≤ 1000V			U > 1000V	
	Insulated	Bare Neutral	Bare Active	Insulated with earthed screen	Insulated without earthed screen
	m	m	m	m	m
A	2.7	2.7	3.7	2.7	3.7
Vertically above those parts of any structure normally accessible to persons					
B	2.0	2.7	2.7	2.7	2.7
Vertically above those parts of any structure not normally accessible to persons but on which a person can stand					
C	1.0	0.9	1.5	1.5	1.5
In any direction (other than vertically above) from those parts of any structure normally accessible to persons, or from any part not normally accessible to persons but on which a person can stand					
D	0.1	0.3	0.6	0.1	0.6
In any direction from those parts of any structure not normally accessible to persons					

Clearance	1000V <U≤ 33kV	33kV <U≤ 132kV	132kV <U≤ 275kV	275kV <U≤ 330kV	330kV <U≤ 500kV
	Bare or covered	Bare	Bare	Bare	Bare
	m	m	m	m	m
A	4.5	5.0	6.5	7.0	8.0
Vertically above those parts of any structure normally accessible to persons					
B	3.7	4.5	6.0	6.5	7.5
Vertically above those parts of any structure not normally accessible to persons but on which a person can stand					
C	2.1	3.0	4.5	5.0	6.0
In any direction (other than vertically above) from those parts of any structure normally accessible to persons, or from any part not normally accessible to persons but on which a person can stand					
D	1.5	2.5	3.5	4.0	5.0
In any direction from those parts of any structure not normally accessible to persons					

The responsible person must consult the network operator.

♦ Reproduced with the permission of Standards Australia Limited © 2016. Copyright in AS/NZS 7000:2016 vests in Standards Australia Limited and Standards New Zealand

2.4 Consideration for construction and maintenance

Designers should consider the implications for safety during construction and future maintenance of buildings and structures in the vicinity of overhead power lines. Provision should be made for the safety of personnel required to access facades during construction and maintenance as required by the *Occupational Safety and Health Act 1984* and the Occupational Safety and Health Regulations 1996 and be included by the designer as part of the construction and future maintenance documentation.

3 Underground Power Cables

3.1 General

Underground power cables are predominately located in road reserves. However, there are locations where power lines have been lawfully placed on private land, and they remain the property of the network operator. The network operator owner is deemed to have right of access to these assets.

Connection equipment to the underground cables is predominately located on private land and by legislation this equipment is to be taken to have been lawfully placed and will continue to be the property of the network operator. The network operator is deemed to have right of access to their assets.

3.2 Equipment types

It is not uncommon for network operators to have multiple cables buried in a single location. Many of these cables can be at different voltages and will require specific safety clearance requirements.

Much of the connection equipment for underground cables sit above the ground. This equipment comprises:

- switchgear housed inside kiosks, compounds and buildings;
- transformers housed inside kiosks, compounds and buildings;
- pillars providing electrical supplies to separate properties; and
- pits providing electrical supplies.

3.3 Technical requirements

Network operators need unimpeded safe access to their assets. Design of buildings, structures and vehicular access must consider the location of network operator assets to ensure equipment access is maintained and is not vulnerable to damage by vehicles.

Excavation at building sites must ensure adequate shoring to protect network operator assets and the safety of site personnel working near electrical equipment.

3.4 Dial Before You Dig

Responsible persons should always confirm the location of underground assets prior to any activity.

Confirmation should occur at the planning and design phases of a building project.

Confirmation of underground assets should be undertaken again before construction begins.

4 Network operators

4.1 Network operator contacts

During planning, design and construction all queries should be made to the relevant network operator.

Horizon Power

Horizon Power, Head Office
Stovehill Road
Karratha WA 6714
karratha@horizonpower.com.au

Western Power

Western Power
GPO Box L921, Perth WA 6842

Rio Tinto Iron Ore

Rio Tinto Iron Ore – Utilities
GPO Box A42
Perth WA 6837

BHP Billiton Iron Ore

BHP Billiton Iron Ore Supply Authority
PO Box 65
Newman WA 6753
Email: supplyauthority@bhpbilliton.com